



MITSUBISHI
FORKLIFT TRUCKS

SERVICE MANUAL

4G63, 4G64 Gasoline Engine

4G63 AA0001-ZZ9999-up

4G64 AA0001-ZZ9999-up

FOREWORD

This service manual has instructions and procedures for the 4G63 and 4G64 gasoline engines. The information, specifications, and illustrations used in this manual are based on information that was current at the time this issue was written.

Correct servicing will give the engines a long productive life. Before attempting to start a test, repair or rebuild job, be sure that you have studied the respective sections of this manual, and know all the components you will work on.

Continuing advancement and improvement of product design may have caused changes to your engines which are not included in this manual.

Whenever a question arises regarding your engines, or this manual, please consult your dealer for the latest available information.

WARNING INDICATION

NOTE

Indicates supplementary explanation.

CAUTION

Indicates items that users must always observe in order to prevent injuries and damage to the vehicle and surrounding area.

TABLE OF CONTENTS

General Information	2
Service specifications	11
Tightening Torque	15
Sealant	18
Special Tools	19
Engine adjustment	22
Alternator and Ignition System	25
Spark Plug Cables	32
Timing Belt	33
Fuel System	39
Lubrication System	41
Cooling System	42
Intake Manifold	44
Exhaust Manifold and Water Pump	46
Rocker Arms and Camshaft	48
Cylinder Head and Valves	53
Front Case and Oil Pan	60
Piston and Connecting Rod	64
Crankshaft and Bylinder Block	71
Carburetor	78
Air Governor	84
Alternator	86
Starter Motor	91
Distributor	99
Troubleshooting	101